



CHROME FENCE RAILING

Installation Instructions

Step 1

Place fence rail on lazy susan and mark hole locations.

Step 2

Drill 7/32" pilot holes per locations marked in Step 1.

Step 3

Press fit fence railing into holes.

If you have any questions or comments
feel free to call our customer service specialists
at 800-626-1126

I-5LSF-03