



LIBERTY HIDDEN COUNTERTOP SUPPORT PLATE INSTALLATION GUIDE

Every successful countertop installation begins with good planning and action. Do not wait until the last minute to order your countertop supports, fasteners or adhesives for installation. Make sure that all aspects of the island support substructure are considered and discussed to ensure that your countertop installation will be smooth and that your countertop support products will be sufficient.

Note that this installation document should not be considered a specific recommendation for your particular application. Federal Brace cannot provide installation guidelines to meet the particulars of every application. This document should be considered a help sheet that provides considerations about the general characteristics of a particular type of support and installation.

Characteristics of the Liberty Hidden Countertop Support Plate

Our Liberty Hidden Countertop Support Plates are designed to allow the maximum amount of leg room possible under a countertop extension or serving bar, on a knee wall application. The Liberty Bracket comes in 1/4" material in the 8"x3" - 12"x3", 3/8" material in the 14"x3" - 18"x3" and 1/2" material in the 20"x3".

Preparations for the Liberty Plates

The Liberty support comes in flat white and raw steel. You will need to finish the raw steel before installation. Make sure you clean the bracket of any machine oil or rust preventative before painting. Once clean and dry apply a metal compatible paint to the bracket completely. Let the first coat dry and do at least 1 more coat. Before installing the brackets the paint should be allowed to dry completely.

Considerations when Installing Liberty Hidden Support Plate

Whenever installing the Liberty Brackets make sure that you are tying into a double 2x4 board. You will want to the fasteners to have as much "biting" material as possible. This will provide with a secure fastening of the brackets. Also, the substructure must be tied into the floor. Remember, a weak substructure makes for a weak installation.

With the substructure in place and sturdy, measure out your bracket pattern. We suggest that you space the Liberty Bracket no greater than 18" apart on a standard application. Once you have your bracket support pattern set up you can attach your first bracket to the substructure. Make sure that when you fasten the Liberty Bracket that you check for a level in all directions. The bracket should be straight and level across the top flange. This will give the best possible support result to your countertop.

You will need to route out the top of your support structure to allow for the 1/4" material thickness of the Liberty Bracket. The top of your bracket should not extend over the top of your support structure but should meet flush with the top. In the

Liberty Bracket design we have allowed an additional 4.125" for the bracket to extend over the substructure.

Once your first bracket is in place you can now add the additional bracket making sure that you check the additional brackets the same way you checked the first. Also, use a level to test each successive bracket installed to make sure that the whole installation is level. Placing the level from bracket to bracket will help you read this aspect of the installation.

Once all the Liberty Brackets are in place you will want to wipe them down to get rid of any handprints or other debris. Just before installation of your counter you may want to apply adhesive or silicone to the top of the bracket to adhere it to the counter. Once the counter is in place you can caulk around the edge of the brackets if you choose. This will give greater adherence to the countertop and cover any gap between the brackets and counter.

Final step is to enjoy your work and your new kitchen counter! We are thankful that you chose to support your beautiful counters with Federal Brace brackets. We would be thankful if you would send us images of your new kitchen and our brackets under your counters. We enjoy seeing Federal Brace supports at work.



Also, know that the highest compliment Federal Brace can be given is a reference from our customers to friends and family. If you have enjoyed your buying experience with Federal Brace please let someone know.

For any questions or comments please to contact us by email at customerservice@federalbrace.com or by phone at (877) 353-8899. If you are a visual learner, check out our installation videos on our YouTube channel Don't forget to share your projects with your new Federal Brace brackets on Twitter and Instagram, just tag us @FederalBrace. Like us on Facebook, and check out our boards on Pinterest for more home improvement/decor and DIY project ideas.



PROUDLY
AMERICAN
MADE

www.federalbrace.com | customerservice@federalbrace.com | 877-353-8899